



PALLET JACK PARTS

Valu-Jack 6600 Frame



Valu-Jack 6600 Backrest & Brake



Valu-Jack 6600 Frame


Item#	Part#	Description	Item#	Part#	Description
1	66201	Set Screw	17	66204	Roll Pin
2	66207	Pin	18	66202	Grease Fitting (Threaded)
3	66203	Lifting Link	19	66217	Load Wheel Axle
4	66205	Snap Ring	20	66220	Bearing
5	66206	Connecting Link	21	66225-D	Load Roller Assembly, Red Ultra Poly On Aluminum Hub W/ Bearings
6	66210	Pin		66225	Load Roller Assembly, Black Ultra Poly On Steel Hub W/ Bearings
7	66208	Push Rod		66225-N	Load Roller Assembly, Nylon W/ Bearings
8	66211	Lifting Link Shaft		66225-S	Load Roller Assembly, Steel W/ Bearings
9	66204	Roll Pin		GWK-VJ-LW	Load Wheel Kit, Incl. (2) Load Roller Assy W/ Bearings, Axles, and Fasteners
10	66214	Push Rod Axle	22	66219	Washer
11	66213	Roll Pin	23	66241	Bolt
12	66216	Roll Pin	24	66242	Nut
13	66212	Pivot Axle	25	66239	Entry Roller
14	66243	Exit Roller	26	66240	Sleeve
15	66244	Bushing			
16	66215	Load Wheel Bracket			

Valu-Jack 6600 Backrest & Brake

Item#	Part#	Description	Item#	Part#	Description
1	66S9	Brake Handle Frame	20	66S24	Bushing
2	66S1	Locking Lever	21	66S25	Shaft
3	66S2	Spring	22	66S29	Bearing
4	66S3	Spring Pin	23	66S30	Snap Ring
5	66S4	Brake Lever	24	66S31	Split Ring
6	66S5	Spring Pin	25	66S32	Washer
7	66S6	Nut	26	66S33	Snap Ring
8	66S7	Bolt	27	66S34	Dust Cover
9	66S8	Brake Cable (Includes Items 7-15)	28	66S13	Shaft
10	66S21	Tube	29	66S15	Set Screw
11	66S10	Bolt	30	66S17	Brake Plate
12	66S11	Washer	31	66S18	Stud
13	66S12	Nut	32	66S19	Brake Shoe
14	66S26	Shaft	33	66S20	Wheel
15	66S14	Nut	34	66S38	Backrest
16	66S27	Shaft	35	66S36	Bushing
17	66S16	Washer	36	66S37	Bolt
18	66S28	Lever Plate			
19	66S35	Washer			

PALLET JACK PARTS

Valu-Jack 6600 Hydraulic Unit



Valu-Jack 6600 Hydraulic Unit

Item#	Part#	Description	Item#	Part#	Description
1	66146	Ball	38	6620	Plug
2 A	66148	Scraper	39	6628	Roll Pin
3 A	66143	O-Ring	40	6627	Handle Bracket
4 A	66144	U-Cup	41	6626	Handle Pin
5	66147	Ram	42	6625	Roll Pin
6	66157	Roll Pin	43	66152	Pressure Roller
7 A	66149	Oil Plug	44	6623	Bushing
8	66145	Shaft	45	669	Roll Pin
9	66156	Pump Body Not Available	46	668	Pin Retainer
10	66114	Retaining Ring	47	667	Spring Cap
11	66121	Bearing Cover	48	66103	Handle Return Spring
12	66122	Thrust Bearing	49	665	Pump Piston
13	66123	Roll Pin	50 A	664	Scraper
14	66118	Traverse	51 A	662	U-Cup
15	66119	Grease Fitting (Threaded)	52	6621	Bushing
16	66120	Snap Ring	53	6622	Shaft
17	66115	Roll Pin	54	66106	Plug
18	66216-HD	Steer Wheel Assembly, Red Ultra Poly On Aluminum Hub W/ Bearings	55	66108	Spring
	66216-ST	Steer Wheel Assembly, Black Poly On Nylon Hub W/ Bearings	56	66109	Valve Cone
	66216-S	Steer Wheel Assembly, Steel W/ Bearings	57	66110	Valve
	GWK-VJ-CK	Complete Wheel Kit, Incl 2 load roller assy, 2 steer wheel assy w/bearings, axles and fasteners	58 A	66111	O-Ring
19	66117	Steer Wheel Axle	59	66112	Valve
20	66128	Bearing	60	66602	Blade Spring
21	66126	Tab Washer	61	66603	Roller
22	66125	Round Nut	63	66604	Roll Pin
23	66124	Hub Cap	64	66605	Roll Pin
24	66129	Spring	65	66606	Roll Pin
25 A	66130	O-Ring	66	66607	Roll Pin
26	66131	Release Pin	67	66608	Control Lever
27 A	66107	O-Ring	68	66609	Pull Rod
28	66136	Release Pin Guide	69	66631	Handle Frame
29 A	66137	Rubber Cushion	70	66632	Bolt
30	66132	Release Lever	71	66633	Lock Washer
31	66134	Lock Nut	72	66612	Chain
32	66133	Adjustment Screw	73	66613	Pin
33	6643	Steel Ball	74	66614	Connecting Screw
34	6644	Ball Base	75	66615	Nut
35	6645	Spring	76	66616	Handle Assembly, Includes Items 60-75
36	6646	Plug	KITS A	66150	Seal Kit
37	6619	O-Ring		66156A	Pump Assembly - New